



# Hisense




CORDLESS  
VACUUM  
CLEANER  
Hi-Style II


QUICK GUIDE









**2/1**



  
 $\leq 75 \text{ dB(A)}$



**Turbo**



1. HANDLE

2. ELECTRICAL BRUSH


3. HANDY VACUUM CLEANER

6. DETACHABLE BATTERY


5. ADAPTER

4. EXTRA ATTACHMENTS






1.




2.









1.



2.





3.






1.





2.






1.




1.



2.









2.













i

i







***Hisense***