

596 mm

[mm]

TOP

center line






573

53.3

141.3

248.7

540 mm



EN Only certain models.
If the following parts are not supplied with your dishwasher, they are not intended for your specific model.

AR	تجزئة موديلات معينة	IT	Solo per alcuni modelli.	RO	Numai la anumite modele.
BG	Само за определени модели.	KK	Тек за неке моделе.	RU	Только в некоторых моделях.
CS	Pouze některé modely.	MK	Само за одређене моделе.	SK	Iba niektoré modely.
CN	僅部分型號。	LT	Tik tam tikri modeliai.	SL	Samo nekateri modeli.
DA	Kun visse modeller.	LV	Vienīgi noteikti modeļi.	SQ	Vatë dhe modele të caktuara.
DE	Nur bei bestimmten Modellen.	NL	Alleen bepaalde modellen.	SR	Samo neki modeli.
ES	Sólo se aplica a determinados modelos.	NO	Bare enkelte modeller.	SV	Endast vissa modeller.
ET	Ainult teatud mudelid.	PL	Dotyczy tylko wybranych modeli.	UK	Тільки в деяких моделях.
FA	فقط برای مدل‌های خاص.				
FI	Vain tietyt mallit.				
FR	Uniquement pour certains modèles.				
HR	Samo za neke modele.				
HU	Csak bizonyos modellekre érvényes.				

1

2

3

4

5

6

6

7

7

8

9

10

11

***** Only Certain Models

***** Only Certain Models

***** Only Certain Models

12

596