



Hisense









HI MOVE IV
HVC6664BK






+







1.




2.




3.




4.




5.



6.




7.




8.




9.




10.




11.






1.



2.



3.








Diagram illustrating the correct and incorrect use of the cordless stick vacuum cleaner. The top section shows the upright mode, and the bottom section shows the angled mode.

Upright Mode (Top Section):

- Left Column (Prohibited uses):**

 - Carpet (checkmark)
 - Hard floor (checkmark)
 - Staircase (cross)
 - Water (cross)

- Right Column (Allowed uses):**

 - Grates (checkmark)
 - Spiders (checkmark)
 - Baseboards (checkmark)
 - Flowers (checkmark)
 - Staircase (cross)
 - Water (cross)

Angled Mode (Bottom Section):








- Left Column (Allowed uses):**





 - Staircase (checkmark)
 - Carpet (checkmark)
 - Staircase (cross)

- Right Column (Prohibited uses):**

 - Water (cross)


The diagram shows the vacuum cleaner in upright, angled, and fully extended positions. A black arrow points to a small button on the side of the angled tube, indicating a locking mechanism.









a




b




c




d




e



f




g











a








b







c







HIGH
≤ 13 min
MEDIUM
≤ 20 min
LOW
≤ 60 min





Filter quick clean



Hisense