

START ▶ light is lit PAUSE II light flashes

SIGNAL LIGHTS ARE ON:

🕲 🗖 when it is

when it is necessary condensate tank;

🕞 📕 when the child lock

STEP 5

END OF DRYING CYCLE

An acoustic signal will indicate the end of the drying cycle. Signal lights will light up and the light on the START/ PAUSE key will flash. **NORM** care Select start delay by (default setting) pressing the button several times (30 min - 24 h).

GENT care for sensitive

temperature.

Countdown will be drying at lower indicated on the display unit above the key.

+ 🌣 extra dry

Press key up to three times to increase the level of laundry dryness and drying time.

🖗 STEAM

Smoothes wrinkles and freshens laundry.

+ T ANTICREASE EXTRA

Prevents creasing if laundry is not taken from the dryer immediately after drying (default is 2 h, possible to set from 0-4 h).

to select the program.

Ø + む = CHILD LOCK Simultaneously press the two keys and hold for 3 sec.



540600en.indd 1



	Problem/error	Cause	What to do?
PROBLEM/ ERROR CAUSE	Laundry is not dried, or drying temperature is longer than 4h.	 Filters are not clean. The room is not sufficiently ventilated. Inappropriate temperature in the room Laundry was not sufficiently wrung or spun. Amount of laundry dried in the appliance is too large or insufficient. 	 Clean the filters. Install the dryer in an appropriate room. Check if the temperature in the room where the dryer is installed is too high (over 25°C) or too low (below 10°C). Laundry inserted into the dryer was not sufficiently wrung or spun, or an inappropriate drying program was selected.
	Unevenly dried laundry.	 The amount of laundry dried at a time is too large. Drying the pieces of different thicknesses Drying the different types of laundry 	 Make sure the laundry is sorted by type and size of items given the selected program.
WHAT TO DO?	Error in the drum lighting.	 There is no lighting when the dryer door is opened. 	 Disconnect the dryer from the power mains and call an authorized service unit.
	On display: F3	 Full condensate tank If the condensate tank is empty, there is a pump failure. 	 Empty the condensate tank. Disconnect the appliance and call the nearest service unit.
	On display: F4	 Clogged filters If the filters are clean, there may be a compressor failure. 	Clean the filters.Disconnect the appliance and call the nearest service unit.
	On display: "LO"	• Steam generator tank is empty	Add distilled water
	Write down the failure (array and a FO, F1 ar F2, disconnect the appliance and call the parter)		

Write down the failure/error code: F0, F1, or F2, disconnect the appliance and call thenearest authorized service (call center).



HOW TO USE YOUR QUICK INSTRUCTIONS RYER

For detailed instructions please read the extended manual.